

YOUR NETWORK RUNS ON COMMScope™

Recommended Installation Method for Powered Fiber



Jan 2017

Separate the fibre from the copper at the rack tie off point.



Take cables 8 ports past target port to obtain correct length.

Start from outside and work in.

Flat cable allows neat storage in bundles of 8



Bundle all 8 cables together up to a point 6 inches to side of PSU before allowing fibre to run upwards to fibre tray





When installing fibre always allow sufficient service loop for fibre tray removal.

For ease of install feed cable from both sides of rack

